2255 Walter Glaub Drive
Plymouth, Indiana 46563
Phone: 800-277-8401

Instructions for Heated Poultry Fountain, Model HPF-100

WARNING: This is an indoor product that requires basic safety precautions to minimize the risk of electrical shock, personal injury, and product damage. Read all directions and precautions carefully before putting into operation.

Important – Use only in a dry sheltered area.

When using this electrical appliance, safety precautions must be followed as described below:

1. **Read all instructions before putting this product into use.**
2. Always disconnect your power cord to the product when not in use and during warm weather.
3. **Do not use the product** when obvious damage is noticed to your supply cord or plug. Inspect cord and plug before using.
4. **Do not use the product** if the product has malfunctioned or has been damaged in any manner.
5. **Do not dismantle or puncture the unit for any reason.** This could cause damage and will void the warranty.

Instructions for Filling the 3 Gallon Reservoir:

1. Line up to the "notches" in the red Drinking Area with the "L" slots on the white Reservoir then press down into place.
2. Turn the white Reservoir clockwise as to lock the white Reservoir into place and open the water flow hole.
3. Turn the **entire** unit upside down to rest on the four legs on top of the white Reservoir. **Do not disassemble!**
4. Remove the black rubber Stopper from the Filling Hole in the center of the red Bottom Cover. **Do not lose the Stopper!**
5. Fill the entire white Reservoir with water then snuggly place the black rubber Stopper back into the Filling Hole.
6. Place your hand underneath the red Handle on the top of the white Reservoir then carefully turn the unit right side up. Water will immediately flow out of the Reservoir into the Drinking Area until it reaches the top of rectangular flow hole.

Instructions for Use: 120 VAC: This unit is recommended for operational use to 0°F!

1. Place the unit directly on a hard and flat surface inside a sheltered area. **Protect from wind!**
2. Plug a heavy-duty fully grounded 16/3 AWG extension cord directly into the units plug.
3. Plug the heavy-duty grounded 16/3 AWG extension cord into a fully grounded 120 VAC GFCI receptacle outlet.
4. Route the extension cord safely away from livestock and place the unit as to protect from damage by livestock.
5. This product is thermostatically controlled to operate only when temperatures fall below 35F.
6. Remove the extension cord when not in use **OR** when filling the reservoir.
7. Inspect the product before using. Read all instructions.

Test for Proper Operation:

(1) Unplug the power and remove the Reservoir from the red Heated Base. (2) Place the red Heated Base into your freezer for approximately 30 minutes to re-set the thermostat. (3) After 30 minutes, remove the unit from the freezer and plug the unit into a known working receptacle outlet. (4) Place your hand flat on the inside of the red Heated Base after five (5) minutes to feel for heat. If the surface is warm to the touch then the red Heated Base is operating correctly.

Limited Warranty

The Heated Poultry Fountain, Model HPF-100 is guaranteed for one year after the original date of consumer purchase or date stamped on the unit against defects due to material and the company's workmanship only. The sole obligation shall be to replace the defective unit with a replacement unit. Units should be "Checked for proper operation" prior to returning as defective. Units must be returned prepaid. No liability for loss or damage of any nature or kind, whether arising out of or from the use of the product, whether defective or not defective, is assumed by Farm Innovators, Incorporated.

Warning

1、Only experienced and healthy adults can install this product by following the instructions.

2、 Keep children away from this product.

3、Do not immerse.

Patent 7,735,455 **© 2018**